






Low Volt Non-Programmable Thermostats Selection Guide

	Model	Schedule Options				User Interface	Application							Power Method		
		Program Options	Energy Star®	Temporary Override	Permanent Hold		Vacation Hold	Stages	Gas, Oil or Electric	Heat Pump	Millivolt	Electric Baseboard	Convactor		Fan-Forced Electric Heater	Radiant Ceiling
	TH1110D1000	Non-Prog					Slide Switches	1 Heat/1 Cool	•	•	•					Dual Powered (Battery and Hardwire)
	TH114-A-024T-15S	Non-Prog					Soft Keys	1 Heat				•	•		•	Hardwire
	TH114-A-024T	Non-Prog					Soft Keys	1 Heat				•	•	•	•	Hardwire
	TH114-AF-024T	Non-Prog					Soft Keys	1 Heat				•	•	•	•	Hardwire
	TH135-01-B	Non-Prog					Soft Keys	1 Heat	•		•	•	•	•	•	Battery
	TH147	7-Day					Slide Switches	1 Heat/1 Cool	•		•					Battery
	TH149	Non-Prog					Slide Switches	1 Heat/1 Cool	•	•	•					Hardwire

* AC112-01 temperature sensor must be ordered separately to have minimum and maximum floor temperature limits

Accessories



AC130-12-P10

NORTH AMERICAN THERMOSTAT WALL PLATE

- Box contains 10 wall plates
- Used for installing TH135, TH146 series and TH149 thermostats